

## Facial Cleaning Brush

### BASIC USER MANUAL

Nonabrasive silicone touch points, gentle enough for all skin types, cleanses significantly more effectively than washing by hand

SUITABLE ALL SKIN

100% waterproof Soft touch switch

USB-rechargeable Soft touch silicone



CONTENTS: Brush, Charge Cord, Pouch, User Manual

Lithium Battery 220mah, 3.7V

### Maintenance and safety

1. Avoid using clay-based, silicone-based or grainy cleansers, exfoliators or scrubs with your brush, you may clean your device by washing the brush surfaces with water and soap, then rinsing with clean water, pat dry with a lint-free cloth or towel, never use cleaning products containing alcohol, petrol or acetone, avoid leaving your device in direct sunlight and never expose it to extreme heat or boiling water.
2. If you experience any discomfort when using this brush, discontinue use immediately and consult a physician, if you suffer from a skin condition, please consult your dermatologist before use, particular care when cleaning the eye regions and do not let the device into contact with the eyelids or eyes themselves.
3. Close supervision is necessary when this device is used by, on, or near children or physically challenged people, never use the device or charging cord if they are damaged. Use this device only for its intended use as described in this manual.
4. We recommend that you do not cleanse for more than 3 minutes at a time.

### Basic instructions on use

**CHARGING:** Always charge your device before first use, USB cable charging head insert into the grooves of product surface, the indicator will flash repeatedly when the device is charging, a process that should take around 1 hour, when the battery is full the indicator will not bright, when the battery is low, the indicator will flash 5 times, while charging your device can not operate, do not charge more than 8 hours. Can be used after full of approximately 100 minutes.

**USAGE:** Press the center button continue 1 second, your device will vibrate, same time the indicator will light, this device will automatically switch itself off after 2 minutes. If you want to stop, press the center button continue 1 second again.

Integrated timer: pulsations will pause every 20 seconds to indicate when you should move the device to another area of the face, pulsations will pause 5 times in succession after 2 minutes to signify the end of cleansing routine. If you wear the makeup, makeup after wet the face with warm water, then put cleanser onto the face, wet brush head with warm water, then press the button on the brush, don't too hard. Starting from the forehead is clean, gently, slowly move the

brush in small circles.(can brush cleanser into head directly, or to apply on the face).

After the use, please rinse clean under water tap, especially silicone points, then spin-dry.

