

UV / LED LAMP ALLE LUX X3

- User manual

Technical data:

Power supply: DC 5V, 2A (via USB 5V)

Max power: 54W

Number of UV LEDs: 18pcs. UV wavelength: 365 + 405nm

Model: X3

Certificate No. : HX1804032126, HX1804032125.

Cures hybrids / UV / LED gels.

Description of elements:

1. Digital display
2. Timer 30s
3. Timer 60s
4. Timer 90s
5. USB power supply connector



User manual:

1. Connect the device to the power supply. The lamp should only be powered from a voltage USB socket 5V!
2. To turn on the lamp, press the timer button - you can choose one of available timer options 30s / 60s / 90s, or start work without selecting the time. For this you should put your hand into the device and the exposure will start automatically when it detects movement by sensor (limit - max 99s).
3. The smart sensor function remembers the last used time in the 30s / 60s / 90s modes.
4. Follow the curing instructions for the product used.
5. After using the lamp, disconnect it from the mains.

Warnings:

- The lamp should be powered only from the 5V USB socket! You can connect it to a computer, power bank or charger with USB port (5V, 1A-2A).
- Protect the device from contact with dust, water and other liquids.
- Disconnect the lamp from the power source when the lamp is not in use or when it is needed cleaning. Do not use the lamp:
 - In damp rooms.
 - If the AC adapter has been damaged.
 - If the device or the connecting cable is damaged.
 - If the timer buttons do not work.
- The machine should not be left running longer than 60 minutes as this can reduce its service life. The device is intended for indoor use.
- It is forbidden to make independent switching and changes to the device.
- Opening the camera is strictly forbidden and tantamount to voiding the warranty, and the manufacturer is not responsible for the correct and safe operation of the device.
- Do not look directly at the UV light, which may damage the eyes. Lamp uses UV / LED diodes which emit dangerous UV rays. They can also cause skin damage. The skin may be more sensitive to UV rays while taking medications or using cosmetics. If you notice any sudden changes in your skin, see your doctor immediately.
- **KEEP AWAY FROM CHILDREN.**

Warranty card no.

Model..... Parameters.....

Price..... Sale date.....

Terms of warranty:

1. The condition for accepting the device for repair is to have a warranty card.
2. Warranty card without completed fields filed with the name of the device, parameters and customer address is invalid.
3. The warranty is valid for twelve months from the date of sale of the device.
4. The defects revealed during this period will be removed for free of charge within no more than 28 days from the date of delivery of the device at the customer's expense and will be returned functional at the guarantor's expense.
5. The guarantee does not exclude, limit or suspend the rights of the buyer resulting from it from the provisions on the warranty for defects in the sold item.
6. The warranty does not include:
 - damage resulting from improper use, storage or maintenance of the device
 - mechanical, thermal, chemical and all other damages what will be intentional or negligent action by the user and what was due at external force
 - UV bulbs for the device
7. The guarantee is valid only on the territory of the Republic of Poland.
8. Person who submits a complaint is obliged to deliver the device to the seller in the original packaging at your expense. Damage caused by insufficient securing of the equipment shipment is not subject to warranty repairs.
9. Loss of warranty:
 - in the case of repairs being an arbitrary action of the user or other unauthorized persons
 - in the event of improper or inconsistent with the instructions for use, maintenance or storage
 - in the case of unauthorized modifications or design changes
10. Under the warranty, the guarantor undertakes to first remove the defect by means of repair of equipment. The buyer is entitled to replace the equipment with a new one only if:
 - a manufacturing defect that cannot be removed was found during the warranty period,
 - in the case when within the warranty period 3 repairs will be required, and the equipment still has defects that make it impossible to operate in accordance with intended use,
 - if there are reasons to replace the equipment with a new one but there are any obstacles that make this exchange impossible, e.g. due to the lack of equipment in stock, the guarantor will refund the price paid.
11. The device is intended for professional and in case of other use the warranty is void.
12. The customer is obliged to describe of the hardware malfunctions and occurring defects and to attach the prepared description for the warranty card.

.....

Customer's signature

Date of request for repair	The date the repair was performed	Repair details	Employee's signature

Customer data:

First name and last name.....

Address

Telephone.....

Company stamp

.....

Date and signature of the seller