

Lamp 9502 LED

User Manual

Ideal for precision work at home, office, study or other workplaces.
Please read the instruction manual before using the device.

Specifications:

Max Power: 14W

Power adapter:

Rated input: **100-240V 0.6A, 50/60HZ**

Rated output: **36V 0.3A**

Number of UV LED: **60 (SMD LED)**

Model: 9502LED

Certificate No: 201100856SHA-V2, 201100856SHA-V1

Assembly and operation of the device:

Attach the clamp to the edge of any horizontal surface of your choice. Insert the lower arm shaft into the hole in the bracket.
Connect the lamp to the power supply.

Lamp dimming instructions::

1. Gradual dimming switch:
ON-100%-75%-50%-25%-OFF
2. Double-clicking locks the setting.
3. If the power is not disconnected, the lamp has the power memory function. When you turn the lamp back on the first time you press the button, the dimmer switch is as before.

Notes and safety of use:

- For internal use only.
- Store and use in dry areas. Keep away from water, moisture. Otherwise, the unit may malfunction and/or be damaged.
- Use in rooms with temperature range: -5°C~40°C.
- Ambient humidity: ≤95%
- If the power cord becomes damaged, replace it with a new one of the same type at a service facility.
- It is forbidden to make unauthorized switchovers or changes to the device.
- Opening the device is categorically prohibited and is equivalent to voiding the warranty, and the manufacturer assumes no responsibility for the proper and safe operation of the device.

IMPORTER

Made in P.R.C.