

# User manual to the Lamp SM 818

## Setting up the unit:

To run the lamp in a continuous, set the switch No. 2 position 2b (-)

To start the lamp timer mode, set the switch No. 2 position 2a (=), and click button No. 1 .

To turn off the lamp, set the switch to the position (o)



## Troubleshooting:

Bulbs don't light up - please check whether all the bulbs are properly inserted into their sockets. To ensure proper curing of UV gels, the bulbs should be replaced after every 500 hours of operation (every 6 months)

Device doesn't work - please contact your supplier.

## Description:

Professional UV nail curing lamp. 36W (4 x 9W) UV lamp cures gel fast as little as 120 seconds.

Leave nails with a beautifully smooth even finish

- Automatic timers: 120 sec
- Wavelength: 370nm.
- Voltage 220V-240V 50-60 Hz

## Notice:

- Don't stare at the UV bulb straightly.
- In order to keep the efficiency, please operate according to the gel manual, don't shorten or use over time.

**LAMPA UV Type: SM-818-L**  
**Power: 36W Input: AC 220V-240V~50Hz**

